72 20 14 90 28 88 22 50 110 66 117 22 87 75 25 74









It is highly recommended that you visit www.metalearth.com/360/ps2001

to see the completed model before assembling your own

## **Premium Series**



## TO CREATE THE BEST CONNECTIONS



## Legends:

Engraved/ Color side

Non - engraved/ Silver side

Attention point

Insert tab and bend 90 degrees

Insert tab and twist 90 degrees

## Assembly tip:

If needed, slightly twist tabs to hold parts together then untwist and bend them down for a nice finish.





- Wire cutters: helpful for taking


helpful for folding parts, bending and twisting tabs.





In order to avoid possible injury from sharp edges, please carefully discard the metal sheets after parts have been removed.







































































<u>A</u> – **5**5

